



**NOTES**

1. ALL DIMENSIONS ARE IN METRES.
2. -- J -- indicates longitudinal joint position.
3. Direction of cross-fall is dependent on curvature.
4. Crowns should be along construction joints.