

Reporting points on Departure – Valletta VTS

1. Vessels leaving Grand Harbour

- When pilot embarks
- Prior to and on departing from berth ATD (Actual Time of Departure)
- At the breakwater
- When the pilot disembarks

Vessels shall remain in VHF radio communication, being ready to give a position report or inform the VTS of the vessel's intentions. Also, to take such direction or advice as the VTS deem necessary.

2. Vessels leaving an Anchorage Areas / Waiting Areas or Conveyance Position:

- On weighing anchor from the designated area or departing from a conveyance position (ATD)

Vessels shall remain in VHF radio communication, being ready to give a position report or inform the VTS of the vessel's intentions. Also, to take such direction or advice as the VTS deem necessary.